PASTORE & LOMBARDI

INNER MOVABLE WALL

- Locking and sliding of the lifting arm guaranteed with one cam and one single pin.
- Automatic lock with vertical wall.
- Automatic lock with horizontal wall.
- Free sliding with wall inclination between 30° and 60°.
- Easier mounting of rail and rack because the lifting arms are supplied without gas springs.
- Possibility to choose the gas springs between 100-150-200-250 kg power.
- Quick and easy mounting and replacing of the gas springs.
- Possibility to choose between MANUAL and AUTOMATIC anchor system with lifted wall.
- Material: pickled and passivated stainless steel AISI 304.



Use standard care and caution and follow these warnings:

- To be fitted with gas springs of only one power value.
- Always mount additional blocking systems (lateral or centred type) to be used with wall in vertical position.
- Install a suitable setscrew onto the rails to avoid sliding out of supports.
- With the panel in horizontal position, ensure that the brake trolley is in a proper position to support the wall.